

D-106 with RP-RAIL-20 Installation

1. If the Inner Channel can't be mounted all the way forward to the chassis, we need to pull it a little backward, so that the mounting holes could match.



2. Since the inner channel is not installed all the way forward to the chassis, there might be a space between the chassis' handle and the mounting bracket. To avoid this, we need to do the following steps:
 - a. Align the end of outer channel with the inner channel



- b. Mount the L Shaped Bracket onto the outer channel. Make sure the end of the bracket could touch the chassis' handle.





- c. Mount another L Shaped Bracket to the other side of the channel. Adjust the position according to the cabinet's length. By doing this, the chassis' handle should touch the cabinet very well.

